

IMPRESSA X9

DECALCIFICATION INSTRUCTIONS



1. Run a De-Calcification when machine displays "DESCALE"



2. Open the sliding door by pressing the push-button on the side of the machine



3. Press the descale button. Display reads "START YES", press descale button to confirm



4. Display reads "EMPTY TRAY"
Slide the drip tray away from the machine and empty the tray



5. Machine displays "EMPTY COFFEE BIN"
Lift the panel up, slide the coffee bin out from the machine, empty coffee bin then re-insert coffee bin first, then insert drip tray



6. Machine displays "INSERT SOLVENT IN TANK" Empty water tank, then place back onto the machine.

NOTE: IF MACHINE IS EQUIPPED WITH THE AUTOMATIC WATER FILL DEVICE, CLOSE THE WATER VALVE FEEDING MACHINE BEFORE PROCEEDING WITH THE DECALCIFICATION PROCEDURE.



7. When the machine is asking for solvent dissolve 3 De-Scale Tablets into 24oz. of water. Then place solution into watertank. Machine will then display "PRESS KEY"
Press the descale button to confirm



8. Place a container underneath the coffee spout, steam wand, and hot water wand
The descale process will take approximately 50 minutes



9. After the machine is finished with the solution, machine displays "WATER TANK, RINSE FILL"
Remove water tank and rinse it thoroughly
Fill watertank and place it back on the machine
NOTE: IF THE MACHINE IS EQUIPPED WITH A WATERLINE KIT, TURN ON THE VALVE AFTER THE SOLUTION HAS FINISHED.



10. Once water tank is on the machine, machine displays "PRESS KEY"
Press **DESCALE** key, to rinse machine



11. After machine rinses, machine displays "EMPTY TRAY".
Slide the drip tray away from the machine and empty the tray



12. Machine will then display "EMPTY COFFEE BIN".
Remove and empty coffee bin, then re-insert the **COFFEE BIN** first, then re-insert **DRIP TRAY** back to the machine. Machine is now ready to use.